9.3 BOTTOM SECTION



BOTTOM SECTION PARTS LIST

Mark	No.	Description	Part No.
	1	MAIN Assy	DWX3190
	2	SEND Assy	DWX3195
	3	ACSW Assy	DWR1490
⚠	4	POWER SUPPLY Assy	DWR1492
⚠	5	AC Inlet Assy	See Contrast table (2)
	6	Connector Assy	DKP3901
	7	Connector Assy	PF06EP-S22
NSP	8	Chassis	DNA1410
	9	Rear Panel	See Contrast table (2)
	10	Bracket PSW	DNF1759
	11	Power Shield	DNF1815
	12	AC Shield	DNF1816
	13	Center Stay	DNF1867
	14	Foot (Rubber)	REC-434
NSP	15	Spacer	AEB7092
	16	PCB Support	AEC7513
NSP	17	Silicon Rubber D5 L	DEB1456
	18	Blind Label	DEC2928
	19	Tape	DEC3053
	20	Holder	VEC1355
	21	Power Knob	DAC2306
	22	Power Knob Guard	DNK4534
	23	Binder	ZCA-SKB90BK
	24	•••••	
	25	•••••	
	26	Washer	DEC2920
	27	Nut	NKX2FTC
	28	Screw	BBZ30P060FTB
	29	Screw	BBZ30P060FTC
	30	Screw	BPZ30P080FTB
	31	Screw	IBZ30P080FTB
	32	Screw	IMZ30P040FTC
	33	Screw	PPZ30P080FTB
	34	Screw	See Contrast table (2)

(2) CONTRAST TABLE

DJM-900NXS/SYXJ8, UXJCB, LXJ, KXJ5 and XJCN5 are constructed the same except for the following:

Mark	No.	Symbol and Description	DJM-900NXS /SYXJ8	DJM-900NXS /UXJCB	DJM-900NXS /LXJ	DJM-900NXS /KXJ5	DJM-900NXS /XJCN5
⚠	5	AC Inlet Assy (2P)	DKP3762	Not used	DKP3762	DKP3762	DKP3762
⚠	5	AC Inlet Assy (3P)	Not used	DKP3927	Not used	Not used	Not used
	9	Rear Panel	DNC2020	DNC2037	DNC2038	DNC2041	DNC2040
	34	Screw	Not used	PMH40P080FTC	Not used	Not used	Not used